

Datasheets, User Guides and Troubleshooting

Hardware

Controllers

CMB16D	16 channel DC controller	User Guide	Datasheet	
CMB16D-QC	16 channel DC controller Deluxe	User Guide		
CTB16D (Blue)	Commercial light controller board, 16 channels, 30 amp (Blue Board)	User Guide	Datasheet	
CTB16D (Green)	Commercial light controller board, 16 channels, 30 amp (Green Board)	User Guide	User Guide	
CT08	Commercial light controller board, 8 channels, 15 amp	User Guide		
CTB08D	Commercial light controller board, 8 channels, 15 amp deluxe	User Guide	Datasheet	
CTB08x V4	Commercial light controller board, 8 channels, 15 amp standard and deluxe	User Guide		
CTB16K (kit)	Residential light controller board, 16 channels, 15 amp kit	User Guide	Datasheet	Troubleshoot
CTB16KV6 (kit)	Residential light controller board, 16 channels, 15 amp kit	User Guide		Troubleshoot
CTB16PC	Residential light controller, 16 channels. 30 amp in PVC enclosure	User Guide	Datasheet	Troubleshoot
CTB16PC (kit)	Residential light controller board, 16 channels. 30 amp kit	User Guide	Datasheet	Troubleshoot
CTB16PCg3	Residential light controller, Generation 3, 16 channels. 30 amp in PVC enclosure	User Guide		
CTB16PCg3 (assembly)	Residential light controller, Generation 3, 16 channels. 30 amp in PVC enclosure assembly process	User Guide		
DC-MP3	Show Director, stand-alone with MP3 player and real-time clock	User Guide	Datasheet	
DIO32	Digital I/O board	User Guide	User Guide	
iDMX-1000	DMX interface to Light-O-Rama data network	User Guide	Datasheet	
LOR1600W	Commercial light controller, 16 channels, 15 amp in metal enclosure	User Guide	Datasheet	
LOR1602MP3	Commercial light controller, 16 channels, 30 amp with Show Director in metal enclosure	User Guide	Datasheet	
LOR1602W	Commercial light controller, 16 channels. 30 amp in metal enclosure	User Guide	Datasheet	
LOR160xWg3	Commercial light controller, Generation 3, 16 channels. 30 amp in metal enclosure	User Guide		
LOR800W	Commercial light controller, 8 channels, 15 amp in metal enclosure		Datasheet	
mDM-MP3	Show Director, stand-alone with MP3 player (no real-time clock)	User Guide	Datasheet	
ServoDog	Servo controller	User Guide	User Guide	

ShowTime Accessories (converters, Cosmic Color Ribbon, wireless)

Converter	Serial to RS-485	User Guide	Datasheet	Troubleshoot
CB100D	Cosmic Color Bulbs	User Guide	Datasheet	
CF2D	Cosmic Color Floods	User Guide	Datasheet	
CR150D	Cosmic Color Ribbon	User Guide	Datasheet	Quickstart
CR150D/CB100D	Cosmic Color Pxl Programming Guide	User Guide		
Easy Light Linker	Wireless data transmitter/receiver (RFV4)	User Guide	User Guide	